

SUPER SERIES
OPERATIONS AND MAINTENANCE
MANUAL

JERR-DAN[®]

An Oshkosh Corporation Company

13224 Fountainhead Plaza
Hagerstown, MD 21742

Phone (717) 597-7111

www.jerr-dan.com

FOREWORD

This manual is intended to serve as a guide to the owner and operator in the safe operation and optimum performance of this Jerr-Dan equipment.

Establishment of good operating habits and familiarity with the equipment and its capabilities combined with good judgement are essential.

Before attempting to operate the unit carefully read all sections of this manual.

Eastern Wrecker Sales Inc

TABLE OF CONTENTS

Certification.....	0.1
Safety.....	1.1
Decal Group.....	1.4
Reporting Safety Defects.....	1.13
Operation	2.1
Maintenance and Lubrication	3.1
Lubrication Chart	3.3
Troubleshooting	3.4

THIS PAGE INTENTIONALLY LEFT BLANK

Eastern Wrecker Sales Inc

NOTICE

MANUFACTURED BY:
DATE OF MANUFACTURE ____ mo. ____ yr.
INCOMPLETE VEHICLE MANUFACTURED BY:
DATE INC. VEH. MFD. ____ mo. ____ yr.
GVWR _____
GAWR FRONT _____ with
_____ tires,
_____ rims, @ _____ psi cold _____
GAWR INTERMEDIATE (1) _____ with
_____ tires,
_____ rims, @ _____ psi cold _____
GAWR INTERMEDIATE (2) _____ with
_____ tires,
_____ rims, @ _____ psi cold _____
GAWR REAR _____ with
_____ tires,
_____ rims, @ _____ psi cold _____

Conformity of the chassis-cab to Federal Motor Vehicle Safety Standards, which have been previously fully certified by the incomplete vehicle manufacturer or intermediate vehicle manufacture, has not been affected by final-stage manufacture. The vehicle has been completed in accordance with the prior manufacturer's instructions, where applicable. This vehicle conforms to all other applicable Federal Motor Vehicle Safety Standards in effect in:

_____ mo. ____ yr.

VEHICLE IDENTIFICATION NUMBER: _____

VEHICLE TYPE: _____

This certification sticker appears on every Jerr-Dan unit mounted on a new chassis and is required by law. Jerr-Dan Corporation will not certify any unit for a capacity greater than the chassis manufacturer's specified rating. **The capacity ratings of Jerr-Dan units do not imply that vehicles can be used without regard to gross vehicle weight ratings (GVWR) or gross axle rating limitations.**

The payload carrying capacity of any truck is determined by the GVWR of the cab chassis, the curb weight of the cab chassis and the weight of the body. It is important that you determine that your truck has satisfactory carrying capacity and axle ratings for your specific application. Jerr-Dan's authorized sales representatives are available to assist you in this regard.

JERR-DAN

An Oshkosh Corporation Company

Rev. _____

Date _____


THIS PAGE INTENTIONALLY LEFT BLANK

SAFETY

Safety is all-important when working with machinery. Accidents happen when established safety practices have been overlooked.


Read and practice all safety points listed in this manual. Safety is the prime responsibility of the operator.

1. Read operating and loading instructions thoroughly.
2. Become familiar with the loads that your unit can safely transport without exceeding the structural capacity of the Jerr-Dan equipment or the gross axle weight ratings, gross vehicle weight rating, and gross combined vehicle weight rating of your chassis.
3. Observe all warning decals.
4. Make sure you are clear of oncoming traffic. Dual controls (driver's side and passenger's side) are standard on your Jerr-Dan roll back.
5. Always put bumper on the ground to support the body and truck frame.




6. Never exceed the rated capacity of the body or truck chassis and its components or use a tow option without a vehicle on the deck.

7. Never winch from the side of the bed. Winch only from the rear with load in line with the winch. Failure to do so can result in winch or wire rope damage. JERR-DAN DOES NOT RECOMMEND THE USE OF SIDE PULLING DEVICES.




8. Always try to winch from the center of the load.
9. Maintain winch cable in good condition. Replace when worn, kinked or frayed. Do not use cable clamps.


10. When loading or unloading the deck and operating the winch, make certain the area behind the load is clear of personnel and obstacles.




11. Distribute load evenly on the deck. Do not concentrate the load on one section of the deck, to the rear of the truck axles, or use a tow option without a load on the deck.




12. Secure cargo to the deck at both the front and rear before the truck is driven. Do not rely on the winch as the only means of holding the load.




13. Keep alert. Do not be distracted during any operating sequences.
14. Do not work behind truck with vehicle on deck unless vehicle is secured at front of deck. (Do not rely on winch.)
15. Keep alert to the location of the C.G. of the load. Tilt when C.G. is at the control station.




16. Insure deck is in the locked position before traveling.
17. Review operator's pre-transport checklist located on the headboard of the deck each time you move a vehicle.
18. Block up deck before performing any service or maintenance work under deck.



DECAL GROUP



(STANDARD DECAL, LEFT SIDE)



(STANDARD DECAL, RIGHT SIDE)

INTERVAL (HOURS)	REF NO.	IDENTIFICATION	SERVICE	LUBRICANT	NO. OF POINTS
JERR-DAN 3IC SUPER SERIES CARRIERS					
50 OR MONTHLY	2	CABLE	OIL	ENGINE OIL	1
	2	WINCH FS CLEVIS (IF APPLICABLE)	LUBE	MPG	1
	5 4	HYD RESERVOIR SUBFRAME PIVOT	CHECK LUBE	* MPG	1 2
250 OR SEMI-ANNUALLY	1	HOLD DOWN GUIDE	OIL	HYD FLUID	2
	3	WINCH GEAR BOX	CHECK	**	1
	6	HYD FILTER	CHANGE	----	1
1000 OPERATING HOURS	3	WINCH GEAR BOX	DRAIN/FILL	**	1
	5	HYD RESERVOIR	DRAIN/FILL	*	1




CHART COVERS ONLY **JERR-DAN** BODY COMPONENTS

* INDICATES DUAL RANGE HYD. FLUID 5 W 20

AUTO TRANS FLUID MAY BE SUBSTITUTED IF NECESSARY

** CONSULT WINCH MANUAL FOR PROPER GRADE AND TYPE

DO NOT GREASE SLIDE PADS

1001127494
REV-00

(LUBRICATION CHART)

JERR-DAN

An Oshkosh Corporation Company



WARNING

WINCH CABLE FAILURE MAY CAUSE INJURY OR DEATH. STAY CLEAR OF CABLE AND LOAD WHEN OPERATING.

BOTH FRONT AND REAR TIE DOWNS MUST BE USED TO SECURE VEHICLE / LOAD TO DECK. DO NOT RELY ON THE WINCH AS THE ONLY MEANS OF HOLDING THE LOAD.

CLUTCH MUST BE TOTALLY ENGAGED BEFORE STARTING THE WINCHING OPERATION.

DO NOT DISENGAGE CLUTCH UNDER LOAD.

DO NOT USE WINCH TO LIFT, SUPPORT OR OTHERWISE TRANSPORT PEOPLE.

A MINIMUM OF 5 WRAPS OF CABLE AROUND THE WINCH DRUM IS NECESSARY TO HOLD THE LOAD. CABLE SETSCREW IS NOT DESIGNED TO HOLD LOAD.

DO NOT EXCEED MAXIMUM LINE PULL RATINGS PUBLISHED IN EQUIPMENT OPERATOR'S MANUAL AND / OR WINCH OPERATING MANUAL.

012

(WINCH)



CAUTION

MAINTAIN OIL LEVEL WITHIN 1/2" OF TOP OF SIGHT GAUGE WITH ALL CYLINDERS FULLY RETRACTED. TORQUE SIGHT GAUGE BOLTS: 8 FT-LBS MAX.

272-02

(HYDRAULIC OIL LEVEL)

IDENT. NO. [REDACTED]

MODEL [REDACTED]

VERSION [REDACTED]

MANUFACTURED BY:
JLG INDUSTRIES, INC.

FOR: **JERR-DAN**

UNDER ONE OR MORE OF
THE FOLLOWING PATENTS:

5,133,633 5,575,606
5,697,741 5,722,810
5,951,235 6,231,294 B1
6,315,515 B1 6,336,783 B1
6,447,239 B2 7,264,305 B2

OTHER PATENTS PENDING

1001132766-A

(SUBFRAME ID)

MANUFACTURED BY:

JLG INDUSTRIES, INC.

FOR: **JERR-DAN**

SERIAL NO. [REDACTED]

MODEL NO. [REDACTED]

1001127221-00


(SERIAL NUMBER)

JERR-DAN

An Oshkosh Corporation Company



(DECK ALIGNMENT)



(TOW OPTION WARNING)



(WHEEL LIFT WARNING)

⚠ WARNING

DO NOT EXCEED TOW OPTION CAPACITIES. OVERLOADING MAY RESULT IN UNSAFE STEERING AND/OR BRAKING CONDITIONS.

PINCH HAZARDS AND MOVING PARTS KEEP CLEAR OF THIS AREA

TOWED VEHICLE MUST BE CONNECTED TO BODY SUBFRAME WITH SAFETY CHAINS

⚠ CAUTION

FULLY RETRACT TOW OPTION BOOM TO AVOID DAMAGE DURING OPERATION OF OTHER CARRIER FUNCTIONS

684

(TOW OPTION WARNING)

⚠ WARNING

HAVE YOU REVIEWED THE OPERATOR'S PRE-TRANSPORT CHECK LIST ON THE UNIT?

139

(CHECKLIST REMINDER)

OPERATOR'S
PRE-TRANSPORT CHECKLIST



CAUTION



REVIEW THIS CHECKLIST BEFORE EACH TOW. FAILURE TO FOLLOW CHECKLIST COULD CREATE A DANGEROUS CONDITION FOR YOU, OTHER MOTORISTS AND PEDESTRIANS, AND MIGHT RESULT IN SERIOUS INJURY OR DEATH.

VEHICLE ON DECK - CHECKLIST:

- HEED ALL WARNINGS ON EQUIPMENT AND CONTROLS.
- DO NOT HOOK CABLE HOOK DIRECTLY TO VEHICLE. USE A HOOK-UP CHAIN, V-STRAP/V-CHAIN ASSEMBLY.
- IS VEHICLE ON DECK ENGINE FORWARD TO AVOID UNLOADING FRONT AXLE OF CHASSIS?
- ARE TWO (2) REAR TIE-DOWN J-HOOKS OR CHAINS SECURELY ATTACHED TO VEHICLE AND DECK?
- IS TOWED VEHICLE IN PARK OR IN GEAR WITH EMERGENCY BRAKE APPLIED?
- DID YOU ATTACH FRONT SAFETY CHAIN/STRAPS TO VEHICLE?
- DO NOT OVERLOAD! SEE LOAD RATING PLACARD ON UNIT. STOP VEHICLE AT ONCE AND REARRANGE LOAD IF YOU NOTICE FRONT END OF TRUCK FEELS LIGHT OR BOUNCES EXCESSIVELY OR IF STEERING FEELS EXCESSIVELY LIGHT. LOSS OF VEHICLE CONTROL CAN RESULT FROM AN OVERLOAD AND CAN CAUSE A SERIOUS ACCIDENT.

VEHICLE ON TOW BAR - CHECKLIST:

- DO NOT LIFT OR TOW A VEHICLE USING THE WHEELIFT SYSTEM UNLESS THERE IS A VEHICLE ON THE DECK.
- DO YOU HAVE TURNING CLEARANCE ON TOWED VEHICLE?
- IS GROUND CLEARANCE SET FOR PROPER TOWING OF SECOND VEHICLE?
- ARE T-HANDLES TIGHTENED SO THAT GRIDS DO NOT MOVE DURING TRANSPORT?
- ARE BOTH WHEEL STRAPS ON TOWED VEHICLE AND TIGHTENED DOWN?
- ARE BOTH SAFETY CHAINS ATTACHED FROM TOWING TRUCK TO TOWED VEHICLE?
- ARE AUXILIARY TOWING LIGHTS ATTACHED TO TOWED VEHICLE?
- DO NOT OVERLOAD YOUR VEHICLE!

© COPYRIGHT 1992 JERR-DAN CORPORATION 275

(CHECKLIST)

JERR-DAN

An Oshkosh Corporation Company

Rev. _____

Date _____



CAUTION

**AIR SUSPENSION MUST BE FULLY
DEFLATED BEFORE TILTING DECK
TO LOAD OR UNLOAD**

176

(SUSPENSION WARNING)

NOTICE

"MAINTENANCE FREE DESIGN"

**SLIDE PAD SYSTEM REQUIRES NO
LUBRICATION AFTER AN INITIAL
COAT OF MOTOR OR HYDRAULIC OIL
ON BEAMS OR SLIDE PADS.
KEEP DECK BEAM SURFACES CLEAN.**

**THE SUBFRAME AND WHEEL-LIFT
SYSTEM IS EQUIPPED WITH
GREASELESS PIVOT JOINTS.
NO LUBRICATION IS REQUIRED.**

502

(SLIDE PAD LUBRICATION)

MANUFACTURED BY: JLG INDUSTRIES, INC.

FOR: **JERR-DAN**

An Oshkosh Corporation Company

13224 Fountainhead Plaza

Hagerstown, MD 21742

Phone (717) 597-7111

www.jerr-dan.com

MODEL NUMBER:

SERIAL NUMBER:

STRUCTURAL CAPACITIES*

MAIN DECK CAPACITY: LBS.*

UPPER DECK CAPACITY: LBS.*

WHEELLIFT/TOWBAR LIFT CAPACITY:
(FULL EXTENSION)

LBS.*

WHEELLIFT/TOWBAR TOW CAPACITY:

LBS.*

HITCH OPTION TONGUE CAPACITY:
(FULL RETRACTION)

LBS.*

HITCH OPTION TONGUE CAPACITY:

LBS.*

***PLEASE READ THE FOLLOWING IN
ORDER TO ENSURE SAFE AND
CORRECT USE OF THE EQUIPMENT.**

DO NOT EXCEED THE ABOVE STRUCTURAL RATINGS.

THE MAXIMUM EFFECTIVE TRANSPORT LOAD
MAY BE LIMITED BY THE GAWR, GVWR OR GCWR
OF THE TRUCK CHASSIS.

THE MAXIMUM EFFECTIVE TRANSPORT LOAD MAY BE
LIMITED BY THE RATINGS OF ANY TOW IMPLEMENTS,
ATTACHMENTS, OR ACCESSORIES BEING USED.

WHEN SUPPLIED, THE SAFETY LOCKING PIN
MUST BE IN PLACE DURING TRANSPORT TO
ACHIEVE THE RATINGS LISTED ABOVE.

SAFETY IS NO ACCIDENT. REVIEW OPERATOR'S
PRE-TRANSPORT CHECKLIST ON VEHICLE AND IN THE
OWNERS MANUAL EACH TIME YOU MOVE A VEHICLE.
FOLLOW ALL INSTRUCTIONS ON CONTROLS AND UNIT.

1001132765-A

(STRUCTURAL RATING PLACARD)


JERR-DAN

An Oshkosh Corporation Company

1.11

Rev. 1

Date 9/14



(WINCH REMOTE AIR FREE-SPOOL)



(PINCH HAZARD)

REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Jerr-Dan Corporation.

If NHTSA receives similar complaints, it opens an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Jerr-Dan Corporation.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to:






Administrator
NHTSA
400 Seventh Street S.W.
Washington, DC 20590

You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>.

THIS PAGE INTENTIONALLY LEFT BLANK

OPERATION

Super Series Carriers operate on the simple concept of a see-saw or teeter-totter. As weight moves from one side of the pivot to the other, gravity wants to make the deck tilt to the side that the weight is on (the pivot point of the deck is just forward of the control station).



A. Controls


The operating controls for the Jerr-Dan equipment are conveniently located on both the driver's and passenger's side.

All operators must be trained and understand the contents of the operator's manual before operating any controls.

Assure adequate operating clearance and the safety of all personnel before operating the rollback equipment.

The following controls are provided:

1. Power-take-off (in truck cab)
2. Auxiliary engine throttle control
3. Rollback control (1st handle)
4. Stabilizer control (2nd handle)
5. Winch control (3rd handle)
6. Tow Option - Extend/Retract (4th handle)




B. Loading the Deck

1. Position

Park the truck in-line with and approximately 13 feet of the equipment to be loaded.


⚠ CAUTION: The unit should always be loaded and unloaded on level and stable ground.

- 1a. Set the parking brake.
- 1b. With the engine running, engage the PTO per instructions in the truck cab or in the PTO Operating Manual.
- 1c. Set the auxiliary throttle. After operating the unit several times, one will establish a feel for the optimum speed. **DO NOT OVERSPEED.**




2. Stabilize

Lower the Tilt/Stabilizer control handle to lower the stabilizer until it is approximately 1 inch off the ground. If the stabilizer should come down in a depression and cannot be extended to within 1 inch of the ground, the vehicle should be moved to a better location or adequate blocking provided to assure support.




3. Roll

Raise the Roll control handle and the deck will slide back. Continue this operation until the deck begins to tilt and the stabilizer rests firmly on the ground. **NEVER ROLL THE DECK BACK UNLESS THE STABILIZER IS DOWN.**



4. Tilt

Raise the Tilt/Stabilizer control handle to retract the stabilizer cylinders allowing the back of the deck to lower to the ground. Use both the Tilt/Stabilizer control handle and the Roll control handle to roll the deck fully rearward while keeping the tip of the deck in light contact with the ground. Make sure the tip of the deck and stabilizer are both resting firmly on the ground before loading.



5. Winch


Winch the load onto the deck. Refer to the Winch Operation Manual for specific winch operation procedures.

- 5a. Raise the Winch control handle to power unreel the winch cable while a second person keeps the cable taut or disengages the winch clutch and free spool the cable. (See the Winch Operation Manual for proper clutch disengagement procedures)

⚠ CAUTION: Never disengage the winch clutch when the winch is under load.

⚠ CAUTION: Always maintain a minimum of 5 wraps of cable on the winch drum.

- 5b. Engage the winch clutch if the winch cable was free spooled. Raise the winch handle (unreel the cable) until the winch clutch fully engages. Ensure that the winch clutch is fully engaged before putting a load on the winch.
- 5c. Attach the winch cable to the load. The winch cable should be attached as close to the center of the load as possible. It may be necessary to use a "V" chain or other implement to attach the winch cable to the load.
- 5d. Lower the Winch control handle to wind the cable onto the winch drum and pull the load onto the deck.



⚠ CAUTION: Always winch load onto deck, **NEVER** drive equipment onto the tilted deck.

⚠ CAUTION: Always maintain a uniform wrap of cable on the drum. “Nesting” of the winch cable may cause damage or premature wear of the winch cable.

⚠ CAUTION: Remember that cables break, winches fail, and hooks become disengaged. **DO NOT WORK BELOW THE LOAD!**

⚠ CAUTION: Replace worn or damaged cables. Always wear gloves when handling cable. **DO NOT USE CABLE CLAMPS.**

⚠ CAUTION: The winch cable should remain attached to the load and taut.


6. Secure Load

Once the load is positioned on the deck secure it from movement in all directions. Set the parking brake or use wheel chocks if applicable.

7. Roll


Lower the Roll control handle to roll the deck forward. Use the Tilt/Stabilizer control handle to keep the tip of the deck in light contact with the ground while rolling the deck forward. Continue this operation only until the balance point of the deck and load nears the control station.

⚠ CAUTION: Rolling the deck too far forward will cause the deck to level (tilt) uncontrolled and may cause damage to the Jerr-Dan equipment, load, or truck chassis, and may cause personal injury.




8. Lower (Tilt)

Lower the Tilt/Stabilizer control handle to extend the stabilizer cylinders. This will level (tilt) the deck. Continue this operation until the deck lays flat on the slide pads on the chassis frame. Do not force the front of the deck against the slide pads.




9. Roll

Lower the Roll control handle to roll the deck forward until it is in the full forward position and under the hold downs.



10. Raise Stabilizer

Raise the Tilt/Stabilizer control handle to fully raise the stabilizer into the transport position.



11. Secure Load

Fully secure the load against movement in all directions. Keyslots are provided at the front and rear of the deck for securing the load. Set brakes (if applicable) and use wheel blocks and tie-downs for safe transport.

⚠ CAUTION: Use safety tie-downs to secure the load against rearward motion. Leave the winch cable attached to the load and taut, but do not rely on the winch cable to secure the load.

12. Disconnect PTO


Return the engine to normal idle speed and disengage the PTO before engaging the transmission. Driving the truck with the PTO engaged will cause overspeeding. Overspeeding of the PTO and/or pump will greatly shorten their life and can cause damage to the PTO, pump, and transmission.

C. Unloading the Deck

1. Position


Park the truck with ample clearance to the back of the deck, approximately 13 feet plus the length of the equipment to be unloaded.

- 1a. Set the parking brake.
- 1b. With the engine running, engage the PTO per instructions in the truck cab or in the PTO Operating Manual.
- 1c. Set the auxiliary throttle. After operating the unit several times one will establish a feel for the optimum speed. **DO NOT OVERSPEED.**




2. Stabilize

Lower the Tilt/Stabilizer control handle to lower the stabilizer until it is approximately 1 inch off the ground. If the stabilizer should come down in a depression and cannot be extended to within 1 inch of the ground, the vehicle should be moved to a better location or adequate blocking provided to assure support.




3. Roll

Raise the Roll handle to roll the deck rearward. Continue this operation until the deck begins to tilt and the stabilizer rests firmly on the ground. NEVER ROLL THE DECK BACK UNLESS THE STABILIZER IS DOWN.




4. Tilt

Raise the Tilt/Stabilizer control handle to retract the stabilizer cylinders allowing the back of the deck to lower to the ground. Use both the Tilt/Stabilizer control handle and the Roll control handle to roll the deck fully rearward while keeping the tip of the deck in light contact with the ground. Make sure the tip of the deck and stabilizer are both resting firmly on the ground before loading.



5. Winch

Winch the load off of the deck. Refer to the Winch Operation Manual for specific winch operation procedures.



- 5a. Ensure that the winch cable is securely attached to the load and is taut. Ensure that the winch clutch is fully engaged (the winch is NOT in free spool mode.)
- 5b. Remove all equipment used to secure the load to the deck (excluding the winch cable). Release brakes of the load (if applicable).
- 5c. Raise the winch control to power unreel the cable from the drum, lowering the load from the deck.


5d. Secure the load on the ground Remove the winch cable from the load and store the cable.

- ⚠ CAUTION:** Never disengage the winch clutch when the winch is under load.
- ⚠ CAUTION:** Always maintain a minimum of 5 wraps of cable on the winch drum.
- ⚠ CAUTION:** Always winch load off of the deck, NEVER drive equipment on the tilted deck.
- ⚠ CAUTION:** Always maintain a uniform wrap of cable on the drum. “Nesting” of the winch cable may cause damage or premature wear of the winch cable.
- ⚠ CAUTION:** Remember that cables break, winches fail, and hooks become disengaged. **DON'T WORK BELOW THE LOAD!**
- ⚠ CAUTION:** Replace worn or damaged cables. Always wear gloves when handling cable. **DO NOT USE CABLE CLAMPS!**

6. Roll


Lower the Roll control handle to roll the deck forward. Use the Tilt/Stabilizer control handle to keep the tip of the deck light contact with the ground while rolling the deck forward. Continue this operation only until the balance point of the deck nears the control station.

- ⚠ CAUTION:** Rolling the deck too far forward will cause the deck to level (tilt) uncontrolled and may cause damage to the Jerr-Dan equipment, load, or truck chassis, and may cause personal injury.




7. Level (Tilt)

Lower the Tilt/Stabilizer control handle to extend the stabilizer cylinders. This will level (tilt) the deck. Continue this operation until the deck lays flat on the slide pads on the chassis. Do not force the front of the deck against the slide pads.




8. Roll

Lower the Roll control lever to roll the deck until it is in the full forward position and under the hold downs.



9. Raise Stabilizer

Raise the Tilt/Stabilizer control handle to fully raise the stabilizer into the transport position.




10. Disconnect PTO

Return the engine to normal idle speed and disengage the PTO before engaging the transmission. Driving the truck with the PTO engaged will cause overspeeding. Overspeeding of the PTO and/or pump will greatly shorten their life and can cause damage to the PTO, pump, and transmission.

D. DOCK LOADING

1. Position the truck within 2-3 feet of the dock.
2. Lower the Tilt/Stabilizer control handle to lower the stabilizer until it rests firmly on the ground.
3. Raise the Roll control handle to roll the deck rearward to the dock. The deck should not be extended more than 4 feet from its transport position during loading.
4. Lower the Tilt/Stabilizer control handle to raise the rear of the deck to the height required for loading.

NOTE: Be careful when positioning the rear of the deck over the dock as the deck may settle when loaded and jam against the dock.

 **CAUTION:** Always center the load (side to side) on the deck.

MAINTENANCE AND LUBRICATION

Jerr-Dan rollback truck decks are designed for years of service with little maintenance. This small amount of maintenance, however, is very important for durability and for safe operation of the deck.

Maintenance is an owner/user responsibility as neither the manufacturer nor the distributor can normally control this function.

Use only safe practices when maintaining this equipment. Never get under a tilted deck unless it is adequately supported (don't rely on the hydraulic system). Always shut off the engine before reaching into pinch areas as when checking the hydraulic oil level or greasing under the deck. Maintain a clean shop for safety. Clean up spilled oil immediately.

Inspect the vehicle and deck system periodically for damage or evidence of pending failure. Damaged or broken parts should be replaced immediately. Never operate a machine which is known to be defective or operating improperly. The cause of any binding or leakage should be determined immediately and the problem promptly fixed.

Sliding surfaces of deck beams are to be cleaned and coated with engine oil periodically. Cleaning every six (6) months is recommended for normal highway operations, but this frequency will vary appreciably with the type of service. Sliding on dirty wear surfaces will cause rapid wear. Fittings on linkage pivots should be greased every two (2) months, again depending upon usage. See Lube Chart.

Check the hydraulic oil level bimonthly or after any leakage. Use 5W20 Dual Range hydraulic oil. (Automatic transmission fluid may be used in the hydraulic system if necessary.)

The proper oil level is best checked by rolling the deck back enough to gain access to the fill plug (unless the chassis configuration caused the oil tank to be mounted abnormally far to the rear). The oil tank should be about 2/3 full with the deck so positioned (shut off the engine after moving the deck). This will result in a 3/4 full tank with the cylinders fully retracted (deck fully forward). (Proper oil level is achieved when the hydraulic oil is within 1/2 inch of top of sight tube.)

The hydraulic filter located on the return side of the hydraulic tank comes equipped with a restriction indicator gauge. This gauge shows the operator the condition of the filter element. When the needle reaches the red band (25 psi), the filter is starting to bypass and the element needs to be changed. Failure to change the element will result in premature wear and/or failure of any or all of the hydraulic components. **Only check gauge with hydraulic fluid at operating temperatures. Cold oil is more dense and will give a false indicator gauge reading.**

If a cylinder seal leaks, disassemble the cylinder and ascertain the cause of the leak. Small scores caused by chips or contaminated fluid can usually be worked out with fine emory cloth to avoid repetition of the trouble. Whenever any seal replacement is necessary, it is always advisable to replace all seals in that component. These seals are available in kits. Also, thoroughly clean all components before reassembly.

LUBRICATION CHART
JERR-DAN
31C SUPER SERIES CARRIERS




CHART COVERS ONLY **JERR-DAN** BODY COMPONENTS

* INDICATES DUAL RANGE HYD. FLUID 5 W 20
AUTO TRANS FLUID MAY BE SUBSTITUTED IF NECESSARY
** CONSULT WINCH MANUAL FOR PROPER GRADE AND TYPE

1001127494
REV-00
DO NOT GREASE SLIDE PADS

INTERVAL (HOURS)	REF NO.	IDENTIFICATION	SERVICE	LUBRICANT	NO. OF POINTS
50 OR MONTHLY	2	CABLE	OIL	ENGINE OIL	1
100 OR BI-MONTHLY	2	WINCH FS CLEVIS (IF APPLICABLE)	LUBE	MPG	1
	5	HYD RESERVOIR	CHECK	*	1
	4	SUBFRAME PIVOT	LUBE	MPG	2
250 OR SEMI-ANNUALLY	1	HOLD DOWN GUIDE	OIL	HYD FLUID	2
	3	WINCH GEAR BOX	CHECK	**	1
	6	HYD FILTER	CHANGE	---	1
1000 OPERATING HOURS	3	WINCH GEAR BOX	DRAIN/FILL	**	1
	5	HYD RESERVOIR	DRAIN/FILL	*	1

TROUBLESHOOTING

PROBLEM

CAUSE

SOLUTION

PROBLEMS ENCOUNTERED WHILE UNIT IS IN TRANSIT

Looseness and rattling of deck	a. Loose Hold Down Blocks	a. Shim Hold Down Blocks as required.
--------------------------------	---------------------------	---------------------------------------

WINCH FUNCTIONING IMPROPERLY

Winch screeches during operation	a. Insufficient lubrication	a. Lubricate per lube chart
Winch will not pull load on deck	a. Free spooling device disengaged b. Insufficient Relief Valve pressure c. Sheared keys or broken chain at coupling d. Hydraulic pump worn	a. Engage b. Reset to correct setting using gauge c. Inspect and replace d. Inspect and replace
Cable build-up on one side of spool or other	a. Off centered load	a. Recenter load if possible

VALVE BANK FUNCTIONING IMPROPERLY

Valve bypasses oil or squeals during all operations	a. Insufficient relief valve setting b. Broken relief spring	a. Reset to correct setting using gauge b. Inspect and replace
Valve handles stick, tight or frozen	b. Broken centering spring or clogged with dirt at bottom of spool	b. Inspect, clean or replace
Valve leaks at top or bottom of spools	a. Defective seals	a. Replace

CYLINDERS FUNCTIONING IMPROPERLY

Cylinders leak oil	a. Defective seals or rod	a. Inspect and replace
Erratic operation of cylinders	a. Air in hydraulic system b. Defective pump (Pulsating)	a. Cycle hydraulic system 10-15 times to remove air b. Replace if necessary

HYDRAULIC SYSTEM FUNCTIONING IMPROPERLY

Slow Operation	a. Low engine RPM b. Low oil level c. Blocked, restricted or collapsed hoses d. Dirty hydraulic oil e. Hydraulic pump worn f. Relief valve in valve bank bypassing	a. Speed up engine b. Reservoir should be 3/4 full with cylinders retracted c. Inspect, remove blockage or reposition hoses affected d. Drain, flush and refill with clean oil e. Rebuild or replace f. 1) Reset to correct pressure using gauge 2) Check if relief spring is broken. Replace if necessary
----------------	---	--

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
P.T.O. FUNCTIONING IMPROPERLY		
Cable tight or frozen	<ul style="list-style-type: none"> a. Cable kinked or bent b. Cable and P.T.O. connection not adjusted properly c. Mounting bracket nuts are over tightened at P.T.O. knob 	<ul style="list-style-type: none"> a. Straighten or replace b. Inspect and adjust c. Loosen if necessary
Rattling noise in P.T.O.	<ul style="list-style-type: none"> a. P.T.O. backlash too loose 	<ul style="list-style-type: none"> a. Shims must be removed (Consult P.T.O. manual)
Howling noise in P.T.O.	<ul style="list-style-type: none"> a. P.T.O. backlash too tight 	<ul style="list-style-type: none"> a. Shims must be added (Consult P.T.O. manual)
Gear oil leak between P.T.O. and pump	<ul style="list-style-type: none"> a. Defective shaft seal 	<ul style="list-style-type: none"> a. Remove and replace
P.T.O. will not engage or disengage	<ul style="list-style-type: none"> a. Cable and P.T.O. connection not adjusted properly b. Defective shifter cover plate 	<ul style="list-style-type: none"> a. Inspect and adjust b. Inspect and replace plate

HYDRAULIC PUMP FUNCTIONING IMPROPERLY

Cavitation: pump unusually noisy	<ul style="list-style-type: none"> a. Low oil supply b. Heavy oil c. Dirty oil filter d. Restriction in suction line 	<ul style="list-style-type: none"> a. Fill to proper level b. Fill with proper oil c. Clean or replace d. Remove
Pump takes too long to respond or fails to respond	<ul style="list-style-type: none"> a. Low oil supply b. Insufficient relief valve pressure c. Pump worn or damaged 	<ul style="list-style-type: none"> a. Fill to proper level b. Reset to correct setting using gauge c. Repair or replace
Oil Heating up	<ul style="list-style-type: none"> a. Foreign material lodged in relief valve b. Using too light oil c. Dirty oil d. Oil level too low e. Insufficient relief valve pressure f. Relief valve pressure too high g. Pump worn (slippage) 	<ul style="list-style-type: none"> a. Inspect and remove b. Drain and refill with clean oil c. Drain, flush, and refill with clean oil d. Fill to proper level e. Set to correct setting using gauge f. Same as "e" g. Repair or replace
Oil foaming	<ul style="list-style-type: none"> a. Air leaking into suction line from tank to pump b. Wrong kind of oil c. Oil level too low 	<ul style="list-style-type: none"> a. Tighten all connections b. Drain and refill with non-foaming type hydraulic oil c. Fill to proper level
Hydraulic oil leak between P.T.O. and pump	<ul style="list-style-type: none"> a. Defective shaft seal 	<ul style="list-style-type: none"> a. Replace shaft seal
Pump leaks at front and rear covers	<ul style="list-style-type: none"> a. Defective seals 	<ul style="list-style-type: none"> a. Replace seals

THIS PAGE INTENTIONALLY LEFT BLANK

Eastern Wrecker Sales Inc



537600063- 2